

## Roof profile closures

Stop ending, or bending up the trays or pans between the profiled ribs of the sheeting, is required at the upper end of all roof sheeting on slopes below 25°. This is to ensure that wind driven rain will not penetrate under the flashing and drain into the ceiling cavity or building space.

Metal end stops are available to close the drip edge rib cavities on other profile roof sheeting ribs. These must be fitted to ensure limited entry of wind blown rain.

Profiled, close cell foam filler strips are available to match the top and bottom of a wide range of sheet profiles. It is critical to ensure that the foam used in the filler strips does not absorb water as this will lead to poultice corrosion of the sheeting and structural steel support.

When sandwiched between the eaves support and underside of the roof sheeting, (and an eaves closure) a bottom profile strip seals against dust, insects, birds, rodents and wind driven rain.

Insertion of the strip between the roof sheeting and hip or ridge flashing will prevent wind driven rain from penetrating the roof cavity.

Filler strips made from ignitable materials must also be avoided, particularly in those areas prone to bush fire hazards as wind blown sparks may initiate ignition of the foam strip contributing to destruction of the building by fire.

BlueScope do not recommend the use of filler strips in situations that may encounter excessive condensation, such as water reservoir roofing.

**If you have any questions regarding this Bulletin, contact  
BlueScope Steel Direct on 1800 800 789.**

**To ensure you have the most current Technical Bulletin,  
please go to [steel.com.au](http://steel.com.au)**



The information and advice contained in this Technical Bulletin ('Bulletin') is of a general nature only and has not been prepared with your specific needs in mind. You should always obtain specialist advice to ensure that the materials, approach and techniques referred to in this Bulletin meet your specific requirements.



BlueScope Steel Limited makes no warranty as to the accuracy, completeness or reliability of any estimates, opinions or other information contained in this Bulletin and to the maximum extent permitted by law, BlueScope Steel Limited disclaims all liability and responsibility for any loss or damage, direct or indirect, which may be suffered by any person acting in reliance on anything contained in or omitted from this Bulletin.

BlueScope is a registered trade mark of BlueScope Steel Limited.

© 2016 BlueScope Steel Limited ABN 16 000 011 058. BlueScope Steel (AIS) Pty Ltd ABN 19 000 019 625. All rights reserved.